



MX401

ROLLS
MADE IN USA
www.rolls.com

Four Channel Stereo Microphone Mixer

LEVEL
CH 1

LEVEL
CH 2

LEVEL
CH 3

LEVEL
CH 4

OUTPUT
LEVEL

clip

STEREO
OUTPUT

POWER
OFF - ON

VDC

BATTERIES
9V x 2

CHANNEL 1 LEVEL LINE MIC
CHANNEL 2 LEVEL LINE MIC
CHANNEL 3 LEVEL LINE MIC
CHANNEL 4 LEVEL LINE MIC

INPUTS

LEFT LEVEL LINE MIC
RIGHT LEVEL LINE MIC

OUTPUTS